

Title:	Steam Injection Steam Temperature			ID:
				0211
Date in:	Response:	Model:	Author:	
2006-08-31	2006-08-31	-	CMA	

Q:

We need information on how the steam controlled humidity, I know basically how it works but not sure to the likes of what temperature the deionised water is heated upto once it enters the Liconic.

A:

The steam is heated to ~140'C and controlled by the RH probe inside the incubator chamber.