

Title:	How does the ActiveX Parameter File work	ID:	
		0124	
Date in:	Response:	Model:	Author:
2003-09-04	2003-09-04	-	CMa

Q:

Does the active-x library require the code from the incubator to be read-out, then the parameters modified, and the code then written back? Are there any risks in this procedure, of making the incubator/carousel un-useable if the download from PC-->PLC fails, or will the PLC always boot in a recovered state, that would permit another re-download if the source file was backed-up?

A:

The parameter file has to sent every time you do a power cycle. It does the same as when you type the changes. So there is no risk.