


Title:	<b>Motor Direction Definition</b>			ID:
				0158
Date in:	Response:	Model:	Author:	
2003-10-28	2003-10-28	STR602	CMa	

## Direction Jumpers STR 602



There are four jumpers the jumper at the innermost position is the direction definition. These jumpers are read during start up.