

Title:	Carrousel does not initialize or turn	ID:	
		0259	
Date in:	Response:	Model:	Author:
2005-03-08	2005-03-08	-	WOp

Carrousel does not initialize or turn

1. check if the door switch is activated (RD 005) should read 1
 - 1) check for small indicator light next to the glass door latch