





# LPX220 Configuration




# 1. Transfer Station Locations




Transfer Station Locations		
	Description	Order Nr.
<b>Case A</b>	Left Side Transfer Location, seen from front	9144 00 91
<b>Case B</b>	Mirrored Transfer Location	9144 00 54
<b>Case C</b>	<b>Standard Transfer Station Location</b>	
<b>Case D</b>	Right Side Transfer Location, seen from front	9144 00 53

## 2. Front Panel Location



Case A	Standard Front Panel Location
Case B	Front Panel on the left side, seen from front
Case C	Front Panel on the back side
Case D	Front Panel on the right side, seen from front

## 3. Connector Panel Location



Case A	Standard Connector Panel Location
Case B	Connector Panel on the right side, seen from front
Case C	Connector Panel on the front side
Case D	Connector Panel on the left side, seen from front

