

Title:	Temperature sensor trouble	ID:	
		0264	
Date in:	Response:	Model:	Author:
2005-03-08	2005-03-08	-	WOp

Temperature sensor trouble

1. when all "000" are displayed in temperature display
2. when very high negative temperature is displayed (less then -25 Deg)
3. when temperature display is not changing at all