

Title:	STX1000 DF Startup Current			ID:
				111
Date in:	Response:	Model:	Author:	
19.01.11		-	CMa	

STX1000-DF Start-up Current at Compressor

Start-up Current	SSS
------------------	-----

17.01.2011	CMa
------------	-----

Compressor	J2192GK
------------	---------

230V/50Hz	Vent. OFF
-----------	-----------

Time	Compressor Current	Evap. Display
[min:sec]	[A]	[°C]
00:00	7.14	21
00:15	6.6	
00:30	5.6	
00:60	5.0	4
01:30	4.7	-5
02:00	4.3	-6
03:00	4.0	-13
04:00	3.6	-22
05:00	3.15	-25
06:00	3.08	-25